


# CORRAPOL<sup>®</sup>-BT

## Durable Bitumen **Corrugated Sheet** Installation Guide




## CORRAPOL®-BT : Installation Guide


CORRAPOL®-BT Corrugated Bitumen Sheet




AWNAPOL® Premium Grade Corrugated Bitumen Sheet




CORRAPOL®-BT Corrugated Bitumen Roof Budget Ridge




CORRAPOL®-BT Foam Eaves filler




Plastic Headed Nails



Screw Cap Fixings




CORRAPOL®-BT Rock n' Lock Side Flashing




CORRAPOL®-BT Super Ridge Gasket (included)

CORRAPOL®-BT Super Ridge

CORRAPOL®-BT Stainless Steel Fixing (included)




CORRAPOL®-BT Rock n' Lock Wall Side Flashing




CORRAPOL®-BT Top Wall Flashing





BACK VIEW



SIDE ELEVATION

CORRAPOL®-BT Super Ridge End Cap

## Tools required



Wear protective gloves and glasses.



Clamp, fine toothed bladed jigsaw and tin snips.



Fine toothed bladed Chop Saw




A hammer, cordless screwdriver/drill, tape measure a straight edge tool and suitable sealant / sealant gun.

## Installation

### 1 MEASURE the roof


**IMPORTANT** - Take all **MEASUREMENTS** of the roof so you can work out the correct plan for the sheet coverage. Allow an **extra 70mm overhang** on the slope length for the sheet overhang.




## 2 DETERMINE OVERLAPS for larger slopes

See diagrams below for overlap, depth and angle details


Fix intermediate roof supports every **two** corrugation peaks




### Roof slopes of 15° or greater: Gradients of 1 in 4 or higher




#### Overlapping sheets



### Roof slopes of 10° – 15°: Gradients of 1 in 6 – 1 in 4




#### Overlapping sheets




Use fixings sheets every corrugation at the eaves and sheet overlaps. Use fixings every other corrugation on intermediate purlins.

### Roof slopes of 5° – 10°: Gradients of 1 in 11 – 1 in 6




#### Overlapping sheets



### 3 Install the CORRAPOL®-BT Foam Eaves Fillers

**IMPORTANT** – To keep the roof watertight and weatherproof, install **CORRAPOL®-BT Eaves Fillers** along fixing points of the roof.

For best performance and sealing install **CORRAPOL®-BT Foam Eaves Fillers** along the horizontal purlins and all fixing points of the roof. These will make installation easier, provide a stronger roof and give greater sealing properties from draughts etc.




### 4 Prepare the CORRAPOL®-BT Rock n' Lock Side Flashing

Cut the aluminium **CORRAPOL®-BT Rock n' Lock Side Flashing** to the required length with a chop saw which has a fine-toothed blade suitable for cutting aluminium.

Cut a mitre at the top end of the **CORRAPOL®-BT Rock n' Lock Side Flashing** so it finishes with a vertical end when offered up to the upper end of the roof slope.

Cut the lower end of the **CORRAPOL®-BT Rock n' Lock Side Flashing** to the same length as the slope, being careful to allow approximately 70mm beyond the eaves beam for an overhang.



**a**  
Pre-drill 5mm pilot holes approximately 250mm apart on the **CORRAPOL®-BT Rock n' Lock Side Flashing**.



**STRAIGHTEN** and **LOCK** the **CORRAPOL®-BT Rock n' Lock Side Flashing** into place giving a perfect finish to the edge of your roof structure.

**TILT** the **CORRAPOL®-BT Rock n' Lock Side Flashing** and **ROCK** the first corrugated sheet peak into the curve of the flashing.


## 5

Prepare the **CORRAPOL®-BT Rock n' Lock Wall Side Flashing**

Cut a mitre edge at the top end of the **CORRAPOL®-BT Rock n' Lock Wall Side Flashing** to the same lengths as the front **CORRAPOL®-BT Rock n' Lock Side Flashing**.

**CORRAPOL®-BT Rock n' Lock Wall Side Flashing** sits directly on timber rafter.

Front elevation of the **CORRAPOL®-BT Rock n' Lock Wall Side Flashing**



### a

Pre-drill suitable sized pilot holes approximately **250mm apart** for fixing the vertical back edge of the **CORRAPOL®-BT Rock n' Lock Wall Side Flashing** to the wall or solid surface. *(Fixing to be supplied by installer)*


Fix the **CORRAPOL®-BT Rock n' Lock Wall Side Flashing** onto the wall using suitable stainless steel screws approximately **250mm** distance between each fixing.

### b

Tilt the **CORRAPOL®-BT Rock n' Lock Wall Side Flashing** to the side and fit the first corrugated sheet peak into the flashing.


### c

Lock the **CORRAPOL®-BT Rock n' Lock Wall Side Flashing** into place giving a waterproof and visually pleasing finish to the wall edge of your roof structure.



## 6


**MEASURE** and **CUT** the **FIRST CORRAPOL®-BT roofing sheet**



## 7 Fit the CORRAPOL®-BT Rock n' Lock Wall Side Flashing and FIRST Corrugated Sheet


### IMPORTANT:

Make sure you use either **PLASTIC HEADED NAILS** or **STAINLESS STEEL SCREWS PLUS FLEXIBLE CAP FIXINGS** through the corrugation peak and not the trough.



When fixing **CORRAPOL®-BT** or **AWNAPOL®** the fixings should be **EVERY PEAK TOP AND BOTTOM** and **EVERY SECOND ON INTERMEDIATE PURLINS**.

**NEVER THROUGH THE TROUGH**




## 8 Prepare the FINAL CORRAPOL®-BT roofing sheets for both sides

### IMPORTANT

To **avoid vertical cuts**, overlap the roofing sheets by **more than two corrugation peaks** to the **EXACT MATCH** of the roof dimensions.


Always finish the roof sheet at the end of a corrugated sheet, **never make a vertical cut**.



## 9 Joint Sheets - end to end overlap example

### JOINING SHEETS (END TO END):

If sheets need to be joined end to end, **ensure an appropriate overlap**, refer to details in **Step 2**.



## 10

Fit the **CORRAPOL®-BT Rock n' Lock Side Flashing** and **Corrugated Sheets**

Fit the remaining **CORRAPOL-BT Corrugate Sheets** plus **CORRAPOL-BT Rock n' Lock Side Flashing** as shown in part 6 to all sides of the roof.

FIX EITHER through the top OR through the side of the bar.



## 11

Install the **NEW CORRAPOL®-BT Super Ridge and End Caps**

Cut the aluminium **CORRAPOL®-BT Super Ridge** to the required length with the fine toothed bladed chop saw.

Pre-drill 5mm pilot holes approximately 250mm apart on the top of the **CORRAPOL®-BT Super Ridge**.

Slide the foam eaves filler into the two side slots of the **CORRAPOL®-BT Super Ridge** before installing onto the roof.

Fit the **CORRAPOL®-BT Super Ridge End Caps** onto either end of the **CORRAPOL®-BT Super Ridge** before fixing onto the peak of the roof.




CORRAPOL®-BT

Fill small 2mm gap between the **CORRAPOL®-BT Ridge End Cap** and the **Super Ridge Bar** with suitable sealant to create a waterproof seal on both sides of the roof.

Measure the distance between the **CORRAPOL®-BT Side Flashing** and **Wall Flashing** allowing an extra 10mm on either side to create an overlap.

Fit lead flashing to create a waterproof seal

Fixings not included



Once the End Caps and Ridge Bar are fully sealed fit onto the peak of the roof


Section view of the **CORRAPOL®-BT Super Ridge Bar** and the **CORRAPOL®-BT Super Ridge End Caps** in place

Cut the end tip of the **CORRAPOL®-BT Ridge End Cap** to fit the space at the back of the **Wall Flashing**

# 12


Alternately install the **CORRAPOL®-BT Budget Ridge** panels

Use **nail or screw fixings** every **two** corrugation peaks  
 Overlap roof ridge panels by the minimum of **22cm**



# 13

Finish of the back wall edge of a Lean-to roof using the **CORRAPOL® Top Wall Flashing**




Lead flashing

Use suitable sealant along the top flat edge between the two bars to give a waterproof seal.

Tilt the angled edge towards the wall to change the pitch variant.

Cut off the Eaves Filler lugs at a **45° angle** to accommodate the curve on the **CORRAPOL® Side and Wall Flashing Bars**.



---

## WARNING : REGISTERED DESIGNS & PATENTS

The IP of the designs in this brochure are protected by internationally registered design rights. Many products are also protected with active or pending Patents. Clear Amber will not hesitate to take appropriate legal action if its rights in this respect are infringed.

© Copyright – Clear Amber Group Ltd – March 2022. No part of this publication may be copied, reproduced, scanned, or stored in any electronic database, whether in whole or in part, in any form or by any means, without permission in writing from Clear Amber. Clear Amber will not hesitate to take appropriate legal action if its rights in this respect are infringed.

Inasmuch as Clear Amber have no control over the circumstances in which our material may be used, or site specific parameters, we cannot guarantee that any particular results will be achieved. Users should carry out their own tests to determine the suitability of the material for their application.